

FIG. 2

<CHKSUM> ÉTX, <Arg2> <Arg1> <STX> <Unit Addr> 8 n Command Structure

N page N page	tr.	Unit	Cmd	1 taomics 6	C tagaina	O.top	Wilsold O
	Otali	Address	Code	טופוווים ויי	Algainent 2	doso	
SET_RELAYS	<stx></stx>	Unit Addr	81	Input No	Hex Val	<xl3></xl3>	<etx> CHKSUM</etx>
SET_DEV_COMMISSION	<stx></stx>	Unit Addr	82	Hex Addr	0=ers/1=en	<etx></etx>	<etx> CHKSUM</etx>
SET_DEV_COMN_ZONE	<stx></stx>	Unit Addr	83	Hex Addr	Zn(A/B/C/D)	<etx></etx>	<etx> CHKSUM</etx>
SET_COMMUNICATIONS	<stx></stx>	Unit Addr	84	BAUD	0	ćΤΧ>	<etx> CHKSUM</etx>
SET_PANEL_ADDR (Prov)	<stx></stx>	Unit Addr	85	NEW ADDR	0	¢TX>	<etx> CHKSUM</etx>
SET_MASTER/SAT_MODE	<stx></stx>	Unit Addr	98	01=Mst/00=Sat	0	¢TX>	<etx> CHKSUM</etx>
SET_ZONES_TO_INPUTS	<stx></stx>	Unit Addr	87	Input No	Hex Val	<etx></etx>	<etx> CHKSUM</etx>
SET_STBY_PWR_MODE	<stx></stx>	Unit Addr	88	01=en/00=dis	0	¢TX>	<etx> CHKSUM</etx>
START_EEPRM_DWNLD	<stx></stx>	Unit Addr	89	00	0	¢TX>	<etx> CHKSUM</etx>
END_EEPROM_CMD	<stx></stx>	Null	8A	70000	Noil	¢TX>	<etx> CHKSUM</etx>

FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7

System Master Programmer File Action Com Port Hetp
Edwards Signaling System Panel Programmer 152
0 - Local Inputs 1 - Relay Assignments 2 - Zone Assignments
3 · Standby/Baud 4 · Device Commissions
Units 00 to 0F
OC Download From Panel Clear ALL New Values Select Unit Address Upload to Panel Finished Modifying Units
Uploading New Config